



HOW TO MEASURE SCREW LENGTHS

Rule of Thumb: Measure where it would sit flush once installed.

